

HONDA

Accord I

Accord (SJ)	(1.6)	76-5/80	AK	12-0150		SU	09-174			
Accord Special (SJ)	(1.6)	80-8/81	AK	12-0150		SU	09-300			

Accord II

Accord EX (AC/AD)	(1.6)	83-5/85	AK	12-0293		AT	09-324			
Accord EX (AC/AD)	(1.6)	83-5/85	AK	12-0501		AT	09-324			
Accord EX (ABS) (AC/AD)	(1.6)	83-5/85	AK	12-0293		AK	12-0291			
Accord EX-Luxe (AAC)	(1.6)	84-8/85	AK	12-0406		AT	09-324			
Accord EX-Aerodeck (AAC)	(1.6)	84/8/85	AK	12-0406		AT	09-324			
Accord Luxe <GB> (AD)	(1.6)	82-7/85	AK	12-0247		AT	09-324			
Accord EX-Luxe (ASY)	(1.6)	84-8/85	SU	12-0245		AT	09-324			
Accord EX-Aerodeck (ASY)	(1.6)	84-8/85	SU	12-0245		AT	09-324			
Accord <GB>	(1.8)	84-7/85	AK	12-0406		AT	09-324			
Accord EX (SY/SZ)	(1.8)	81-6/83	AK	12-0501		AT	09-324			
Accord EX-Aerodeck (SY/SZ)	(1.8)	81-6/83	SU	12-0245		AT	09-324			
Accord EX (AC/AD)	(1.8)	83-6/85	AK	12-0293		AT	09-324			
Accord EX (AC/AD)	(1.8)	83-6/85	AK	12-0501		AT	09-324			
Accord EX (CA1)	(1.8)	85-7/87	AK	12-0350		AK	09-326			
Accord EX-R (AAD)	(1.8)	83-6/85	AK	12-0406		AT	09-324			
Accord EX-R (AAD) (ABS)	(1.8)	83-6/85	AK	12-0406		AK	12-0291			
Accord Luxe (AD)	(1.8)	82-7/85	AK	12-0247		AT	09-324			
Accord Luxe (AD)	(1.8)	83-6/85	AK	12-0406		AT	09-324			

Accord III

Accord EL-LX (CA/CA5)	(1.6)	9/85-9/89	AK	12-0349		AT	09-324			
Accord EL-LX (CA/CA5)	(1.6)	9/85-9/89	AK	12-0503		AT	09-324			
Accord LS-S (CG7-CH5)	(1.6)	10/98-1/03	SU	12-0904		TRW	09-611			
Accord LS-S (CG7-CH5) (ABS)	(1.6)	10/98-1/03	SU	12-0904		TRW	12-0976			
Accord EX-R (CA)	(1.8)	85-7/86	AK	12-0350		AK	12-0351			
Accord EX-R (BA/CA)	(1.8)	85-7/87	AK	12-0349		AT	09-324			
Accord EX-EXC-Luxe (CA4/5)	(2.0)	9/85-12/87	AK	12-0503		AT	09-324			
Accord EX-EXC-Luxe (ABS)	(2.0)	9/85-12/87	AK	12-0349		AK	12-0351			
Accord LX-Aerodeck (CA4/5)	(2.0)	9/85-12/87	AK	12-0503		AT	09-324			
Accord LX-Aerodeck (ABS)	(2.0)	9/85-12/87	AK	12-0349		AK	12-0351			
Accord DX-LX (CA/6)	(2.0)	1/88-12/89	AK	12-0349		AT	09-324			
Accord EL-EX-Aerodeck (CA5)	(2.0)	1/88-12/89	AK	12-0371		AT	09-324			
Accord EL-EX-R-Aerod.(ABS)	(2.0)	1/88-12/89	AK	12-0371		AK	12-0351			
Accord Luxe-LX-Aerod. (CA5)	(2.0)	1/88-12/89	AK	12-0371		AT	09-324			
Accord Luxe-Aerodeck (ABS)	(2.0)	1/88-12/89	AK	12-0371		AK	12-0351			
Accord Luxe-EX-S (CA5)	(2.0)	1/88-12/89	AK	12-0371		AK	12-0351			
Accord LX (CA/6)	(2.0)	1/88-12/89	AK	12-0371		AK	12-0351			
Accord LX-SE (CA/6)	(2.0)	1/88-12/89	AK	12-0480		AK	12-0351			
Accord Coupé (CB7)	(2.0)	89-11/93	SU	12-0519		AK	12-0544			
Accord Coupé (CB9)	(2.0)	89-11/93	AK	12-0543		AK	12-0544			

Accord IV

Accord EX-LX (CB1/3-CC1)	(1.8)	1/90-12/91	AK	12-0482		AK	09-439			
Accord DX-EX (CB3/5)	(2.0)	1/90-12/92	AK	12-0482		AK	09-439			
Accord DX (ABS) (CB1/3/5)	(2.0)	1/90-12/92	AK	12-0482		AK	12-0483			
Accord EX (ABS) (CB1/3/5)	(2.0)	1/90-12/92	AK	12-0482		AK	12-0483			
Accord LX-Special (CB3/5)	(2.0)	1/90-12/92	AK	12-0482		AK	09-439			
Accord LX (ABS) (CB1/3/5)	(2.0)	1/90-12/92	AK	12-0482		AK	12-0483			
Accord Spec.(ABS) (CB1/3/5)	(2.0)	1/90-12/92	AK	12-0482		AK	12-0483			
Accord Coupé (CC1)	(2.0)	4/92-5/94	AK	12-0482		AK	12-0483			
Accord ES Coupé (CD7)	(2.2)	9/89-7/93	AK	12-0482		AK	12-0483			
Accord EX-EX 4WD (CB7)	(2.2)	1/90-12/92	AK	12-0648		AK	12-0544			
Accord EX-EX 4WD (CB7)	(2.2)	1/90-12/92	AK	12-0519		AK	12-0544			
Accord Aerodec (CB8/9-CC1)	(2.2)	1/90-10/97	AK	12-0543		AK	12-0544			
Accord Aerodec (CB8/9-CC1)	(2.2)	1/90-10/97	AK	12-0519		AK	12-0544			

Accord V

Accord ES-LS-S (CE7)	(1.8)	1/96-9/98	AK	12-0543		AK	12-0544			
Accord ES-LS-S (CE7)	(1.8)	1/96-9/98	AK	12-0621		AK	12-0544			
Accord Aerod. (CV8/9-CC9)	(2.0)	1/93-12/93	AK	12-0543		AK	12-0483			
Accord ES-LS-S (CC7-CE8)	(2.0)	1/93-9/98	AK	12-0621		AK	12-0544			
Accord ES-LS-S (ABS)	(2.0)	1/93-9/98	AK	12-0543		AK	12-0544			
Accord ES-LS Aerod.(CE2)	(2.0)	1/93-12/93	AK	12-0543		AK	12-0544			
Accord LE-LX Aerod.(CC9)	(2.0)	1/94-10/97	AK	12-0543		AK	12-0544			
Accord LS Coupé (115HP)	(2.0)	9/93-2/98	AK	12-0648		AK	12-0544			

HONDA

Accord TDi (CF1)	(2.0)	1/93-9/98	AK	12-0621		AK	12-0544			
Accord TDi (CF1) (ABS)	(2.0)	1/93-9/98	AK	12-0543		AK	12-0544			
Accord ES Coupè (CD7)	(2.2)	8/93-12/97	AK	12-0543		AK	12-0544			
Accord Vtec 16V (CE9)	(2.2)	1/96-9/98	AK	12-0621		AK	12-0544			
Accord Vtec 16V(ABS)(CE9)	(2.2)	1/96-9/98	AK	12-0543		AK	12-0544			
Accord SR (CC7)	(2.3)	1/93-12/95	AK	12-0621		AK	12-0544			
Accord SR (ABS) (CC7)	(2.3)	1/93-12/95	AK	12-0543		AK	12-0544			
Accord VI										
Accord Vtec-ES-LS-S (CH6)	(1.8)	10/98-1/03	SU	12-0870		TRW	12-0976			
Accord TDiC LS (ABS)	(2.0)	10/98-1/03	SU	12-0870		TRW	12-0976			
Accord Vtec (CG9-CH2/7/8)	(2.0)	10/98-1/03	SU	12-0870		TRW	12-0976			
Accord VII										
Accord (CL8)	(2.0)	2/03-	AK	12-1117		TRW	12-0976			
Accord VTEC	(2.0)	2/03-	AK	12-1185		TRW	12-0976			
Accord VTEC (Tourer)	(2.0)	2/03-	AK	12-1185		AK	12-0544			
Accord CDTi	(2.2)	2/03-	AK	12-1185		TRW	12-0976			
Accord CDTi (Tourer)	(2.2)	2/03-	AK	12-1185		AK	12-0544			
Accord CDTi	(2.2)	1/04-	AK	12-1117		TRW	12-0976			
Accord (CL9)	(2.4)	2/03-	AK	12-1117		TRW	12-0976			
Accord VTEC	(2.4)	2/03-	AK	12-1185		TRW	12-0976			
Accord VTEC (Tourer)	(2.4)	2/03-	AK	12-1185		AK	12-0544			
Accord (Tourer)		2/03-					09-713			(P)
Accord VIII										
Accord VTEC - VTEC (Tourer)	(2.0)	2/08-	AT	12-1369		NI	12-1370			
Accord VTEC - VTEC (Tourer)	(2.0)	2/08-	AT	12-1369		AK	12-1374			
Accord VTEC - VTEC (Tourer)	(2.0)	7/08-	AK	12-1373		NI	12-1370			
Accord VTEC - VTEC (Tourer)	(2.0)	7/08-	AK	12-1373		AK	12-1374			
Accord DTEC - DTEC (Tourer)	(2.2)	2/08-	AT	12-1369		NI	12-1370			
Accord DTEC - DTEC (Tourer)	(2.2)	2/08-	AT	12-1369		AK	12-1374			
Accord DTEC - DTEC (Tourer)	(2.2)	7/08-	AK	12-1373		NI	12-1370			
Accord DTEC - DTEC (Tourer)	(2.2)	7/08-	AK	12-1373		AK	12-1374			
Accord VTEC - VTEC (Tourer)	(2.4)	2/08-	AT	12-1369		NI	12-1370			
Accord VTEC - VTEC (Tourer)	(2.4)	2/08-	AT	12-1369		AK	12-1374			
Accord VTEC - VTEC (Tourer)	(2.4)	7/08-	AK	12-1373		NI	12-1370			
Accord VTEC - VTEC (Tourer)	(2.4)	7/08-	AK	12-1373		AK	12-1374			
Ballade										
Ballade <GB>	(1.3)	84-6/85	SU	12-0245		AK	09-325			
Ballade <GB>	(1.5)	84-6/85	SU	12-0245		AK	09-325			
Ballade EX <GB>	(1.6)	4/86-12/89	AK	12-0349		AT	09-324			
Ballade EX <GB>	(1.8)	4/86-12/89	AK	12-0349		AT	09-324			
City										
City	(1.2)	8/80-12/83	AK	12-0292		SU	09-300			
Civic I										
Civic (SB1)	(1.2)	72-75	SU	12-0081		SU	09-174			
Civic (SB2)	(1.2)	75-5/80	SU	12-0095		SU	09-174			
Civic (SEA-SEB)	(1.5)	73-5/80	SU	12-0095		SU	09-174			
Civic Van	(1.5)	75-5/80	SU	12-0198		AK	09-268			
Civic Wagon	(1.5)	75-5/80	SU	12-0198		AK	09-268			
Civic L (SEA-SEB)	(1.5)	1/74-5/78	SU	12-0095		SU	09-174			
Civic II										
Civic (ASL) - GL (ASP)	(1.2)	1/81-12/83	SU	12-0290		SU	09-300			
Civic Wagon (AWC)	(1.3)	1/80-12/81	AK	12-0150		SU	09-327			
Civic Hatchback (ASL/P/S)	(1.3)	1/82-12/83	SU	12-0290		SU	09-327			
Civic DX (ASL-ASS)	(1.3)	1/82-12/83	SU	12-0290		SU	09-300			
Civic DX Wagon (AWC)	(1.3)	1/82-12/83	AK	12-0150		SU	09-327			
Civic EX (ASL-ASS)	(1.3)	1/80-12/81	SU	12-0176		SU	09-300			
Civic EX Wagon (AWC)	(1.3)	1/80-12/81	AK	12-0150		SU	09-327			
Civic GL (ASP-AWC)	(1.3)	1/82-12/83	SU	12-0290		SU	09-300			
Civic L (ASL)	(1.3)	1/80-12/81	SU	12-0176		SU	09-300			
Civic L Wagon (AWC)	(1.3)	1/80-12/81	AK	12-0150		SU	09-327			
Civic L (ASL-ASS)	(1.3)	1/82-12/83	SU	12-0290		SU	09-300			
Civic Hatchback (SL-SR)	(1.3)	80-81	SU	12-0176		SU	09-300			
Civic Hatchback (SL-SR)	(1.3)	81-1/84	SU	12-0288		AK	09-325			
Civic (SL-SR) <USA>	(1.3)	80-82	SU	12-0244		SU	09-300			
Civic Sedan	(1.5)	80-8/83	SU	12-0115		SU	09-300			

HONDA

Civic III

Civic Special (AAM)	(1.2)	1/85-12/87	SU	12-0288		AK	09-325		
Civic DX (AAL)	(1.2)	1/84-12/87	SU	12-0288		AK	09-325		
Civic <GB> (AG/AM)	(1.2)	84-6/85	SU	12-0245		AK	09-325		
Civic Bali (EG3)	(1.3)	1/93-12/95	AK	12-0289		AK	09-325		
Civic EX (AAG-AAJ)	(1.3)	1/84-12/87	SU	12-0288		AK	09-325		
Civic GL (AAG)	(1.3)	1/84-12/87	SU	12-0288		AK	09-325		
Civic L (AAJ)	(1.3)	1/84-12/87	SU	12-0288		AK	09-325		
Civic Luxe (AAG-AAJ)	(1.3)	1/84-12/87	SU	12-0288		AK	09-325		
Civic Van 4WD	(1.5)	6/85-12/87	SU	12-0245		AK	09-326		
Civic Wagon	(1.5)	80-84	AK	12-0150		SU	09-327		
Civic (AAH-AAK)	(1.5)	83-12/87	SU	12-0288		AK	09-325		
Civic DL-DX (AAH)	(1.5)	1/84-12/87	SU	12-0288		AK	09-325		
Civic GL-GT (AAH-AAK)	(1.5)	1/84-12/87	SU	12-0288		AK	09-325		
Civic L-LX-SLX (AAH-AAK)	(1.5)	1/84-12/87	SU	12-0288		AK	09-325		
Civic (SL-SR) <USA>	(1.3)	83-1/84	SU	12-0290		AK	09-325		

Civic IV

Civic DX (EC7-ED1)	(1.2)	1/88-12/91	AK	12-0501		AK	09-325		
Civic DX (EC8)	(1.3)	1/88-12/91	AK	12-0289		AK	09-325		
Civic S (ASL-AWC)	(1.3)	1/82-12/83	SU	12-0290		SU	09-300		
Civic Sport (ASL)	(1.3)	1/82-12/83	SU	12-0290		SU	09-300		
Civic Luxe (EC8)	(1.3)	1/88-12/91	AK	12-0501		AK	09-325		
Civic GL-GLX (3 doors) (ED2)	(1.4)	1/88-12/91	AK	12-0479		AK	09-325		
Civic GL-GLX (4 doors) (EC9)	(1.4)	1/88-12/91	AK	12-0501		AK	09-325		
Civic Shuttle (EE1)	(1.4)	1/88-12/89	AK	12-0406		AK	09-326		
Civic Shuttle (EE1)	(1.4)	1/90-12/91	AK	12-0479		AK	09-326		
Civic (ED6)	(1.5)	1/88-12/88	AK	12-0350		AK	09-325		
Civic (ED6)	(1.5)	1/89-12/91	AK	12-0479		AK	09-325		
Civic DX (ED6)	(1.5)	1/88-12/88	AK	12-0350		AK	09-325		
Civic DX (ED3/6)	(1.5)	1/88-12/91	AK	12-0479		AK	09-325		
Civic GL (ED6)	(1.5)	1/88-12/88	AK	12-0350		AK	09-325		
Civic GL (ED3/6)	(1.5)	1/88-12/91	AK	12-0479		AK	09-325		
Civic (ED3/4/6/7) <USA>	(1.5)	88-89	AK	12-0406		AK	09-325		
Civic Shuttle 4WD (AR)	(1.5)	9/85-1/88	SU	12-0245		AK	09-326		
Civic Shuttle TRWxe (AN)	(1.5)	9/83-1/88	SU	12-0288		AK	09-326		
Civic Shuttle TRWxe (AN)	(1.5)	9/83-1/88	AK	12-0407		AK	09-326		
Civic Shuttle Van (AN)	(1.5)	9/85-1/88	SU	12-0245		AK	09-326		
Civic Shuttle Van (AN)	(1.5)	9/85-1/88	AK	12-0407		AK	09-326		
Civic Shuttle (Cat.)	(1.5)	2/88-12/89	AK	12-0406		AK	09-326		
Civic Shuttle GL (EE1/2)	(1.5)	6/88-1/92	AK	12-0406		AK	09-326		
Civic Shuttle GL Van 4WD	(1.5)	6/88-1/92	AK	12-0479		AK	09-326		
Civic (3/4 Drs)	(1.6)	2/87-88	AK	12-0501		AK	09-325		
Civic 4x4 (EE5)	(1.6)	1/88-12/88	AK	12-0350		AK	09-326		
Civic 4x4 (EE5)	(1.6)	1/89-12/91	AK	12-0479		AK	09-326		
Civic FWD (ED4/7)	(1.6)	1/88-12/91	AK	12-0479		AK	12-0351		
Civic 4x4 (ED3/4/6/7) <USA>	(1.6)	88-89	AK	12-0406		AK	09-325		
Civic Shuttle 4WD (Cat.)	(1.6)	2/88-10/91	AK	12-0406		AK	09-326		
Civic Shuttle 4WD (ABS)	(1.6)	11/91-2/95	AK	12-0479		AK	09-326		

Civic V

Civic DX (EC7-ED1)	(1.2)	1/88-12/91	AK	12-0501		AK	09-325		
Civic DX (EC8)	(1.3)	1/88-12/91	AK	12-0289		AK	09-325		
Civic S (ASL-AWC)	(1.3)	1/82-12/83	SU	12-0290		SU	09-300		
Civic Sport (ASL)	(1.3)	1/82-12/83	SU	12-0290		SU	09-300		
Civic Luxe (EC8)	(1.3)	1/88-12/91	AK	12-0501		AK	09-325		
Civic GL-GLX (3 doors) (ED2)	(1.4)	1/88-12/91	AK	12-0479		AK	09-325		
Civic GL-GLX (4 doors) (EC9)	(1.4)	1/88-12/91	AK	12-0501		AK	09-325		
Civic Shuttle (EE1)	(1.4)	1/88-12/89	AK	12-0406		AK	09-326		
Civic Shuttle (EE1)	(1.4)	1/90-12/91	AK	12-0479		AK	09-326		
Civic (ED6)	(1.5)	1/88-12/88	AK	12-0350		AK	09-325		
Civic (ED6)	(1.5)	1/89-12/91	AK	12-0479		AK	09-325		
Civic DX (ED6)	(1.5)	1/88-12/88	AK	12-0350		AK	09-325		
Civic DX (ED3/6)	(1.5)	1/88-12/91	AK	12-0479		AK	09-325		
Civic GL (ED6)	(1.5)	1/88-12/88	AK	12-0350		AK	09-325		
Civic GL (ED3/6)	(1.5)	1/88-12/91	AK	12-0479		AK	09-325		
Civic (ED3/4/6/7) <USA>	(1.5)	88-89	AK	12-0406		AK	09-325		
Civic Shuttle 4WD (AR)	(1.5)	9/85-1/88	SU	12-0245		AK	09-326		

HONDA

Civic Shuttle TRWxe (AN)	(1.5)	9/83-1/88	SU	12-0288			AK	09-326			
Civic Shuttle TRWxe (AN)	(1.5)	9/83-1/88	AK	12-0407			AK	09-326			
Civic Shuttle Van (AN)	(1.5)	9/85-1/88	SU	12-0245			AK	09-326			
Civic Shuttle Van (AN)	(1.5)	9/85-1/88	AK	12-0407			AK	09-326			
Civic Shuttle (Cat.)	(1.5)	2/88-12/89	AK	12-0406			AK	09-326			
Civic Shuttle GL (EE1/2)	(1.5)	6/88-1/92	AK	12-0406			AK	09-326			
Civic Shuttle GL Van 4WD	(1.5)	6/88-1/92	AK	12-0479			AK	09-326			
Civic (3/4 Drs)	(1.6)	2/87-88	AK	12-0501			AK	09-325			
Civic 4x4 (EE5)	(1.6)	1/88-12/88	AK	12-0350			AK	09-326			
Civic 4x4 (EE5)	(1.6)	1/89-12/91	AK	12-0479			AK	09-326			
Civic FWD (ED4/7)	(1.6)	1/88-12/91	AK	12-0479			AK	12-0351			
Civic 4x4 (ED3/4/6/7) <USA>	(1.6)	88-89	AK	12-0406			AK	09-325			
Civic Shuttle 4WD (Cat.)	(1.6)	2/88-10/91	AK	12-0406			AK	09-326			
Civic Shuttle 4WD (ABS)	(1.6)	11/91-2/95	AK	12-0479			AK	09-326			
Civic V											
Civic DX (EG3)	(1.3)	1/92-12/95	AK	12-0501			AK	09-618			
Civic Splasch-Twenty (EG3)	(1.3)	1/93-12/95	AK	12-0289			AK	09-325			
Civic (MA8)	(1.4)	2/95-12/96	TRW	12-0502			TRW	09-440			
Civic (MA8) (ABS)	(1.4)	2/95-12/96	TRW	12-0502			AK	12-0530			
Civic (EJ2)	(1.5)	2/94-12/95	AK	12-0547			AT	09-324			
Civic Bali (EG8)	(1.5)	8/94-12/95	AK	12-0547			AT	09-324			
Civic DXi-LSi (EG8-EJ2)	(1.5)	1/92-12/95	AK	12-0547			AK	09-618			
Civic DXi-LSi (EG4)	(1.5)	1/92-12/95	AK	12-0547			AK	09-499			
Civic VTEC-E (EG4)	(1.5)	1/92-12/95	AK	12-0547			AT	09-324			
Civic VTEC-E (ABS) (EG8)	(1.5)	1/93-12/95	AK	12-0547			AK	12-0548			
Civic VTEC-E (MA8)	(1.5)	2/95-12/96	TRW	12-0502			TRW	09-440			
Civic VTEC-E (ABS) (MA8)	(1.5)	2/95-12/96	TRW	12-0502			AK	12-0530			
Civic (EH3) <USA>	(1.5)	1/92-12/95	AK	12-0736			AK	12-0530			
Civic (EG8-EH9) <USA>	(1.5)	1/92-12/95	AK	12-0736			AK	12-0530			
Civic (EG8-EH9) <USA>	(1.5)	8/91-92	AK	12-0190			AK	12-0530			
Civic Bali (EG9)	(1.6)	8/93-12/95	AK	12-0546			AK	12-0548			
Civic ESi VTEC (EH9)	(1.6)	8/91-12/92	AK	12-0547			AK	09-618			
Civic ESi VTEC (EH9) (ABS)	(1.6)	8/91-12/94	AK	12-0546			AK	12-0548			
Civic ESi VTEC (EG5)	(1.6)	1/92-12/95	AK	12-0547			AK	12-0548			
Civic ESi VTEC (EJ1)	(1.6)	8/93-12/95	AK	12-0546			AT	09-324			
Civic EXi (EH9) (ABS)	(1.6)	8/93-12/95	AK	12-0546			AK	12-0548			
Civic VTEC (EE9)	(1.6)	1/90-12/91	AK	12-0479			AK	12-0351			
Civic VTi VTEC (EG5)	(1.6)	1/92-12/92	AK	12-0547			AK	12-0548			
Civic VTi VTEC (EG6/9)	(1.6)	1/92-12/95	AK	12-0546			AK	12-0548			
Civic (EG8-EH9) <USA>	(1.6)	8/91-92	SU	12-0190			AK	12-0530			
Civic (EG8-EH8/9) <USA>	(1.6)	1/92-12/95	AK	12-0736			AK	12-0548			
Civic VI											
Civic (EJ9)	(1.4)	1/96-12/97	AK	12-0547			AK	09-618			
Civic LS-S (EJ9)	(1.4)	1/96-12/97	AK	12-0547			AT	09-324			
Civic Eco-Joker (EJ9)	(1.4)	1/96-12/97	AK	12-0547			AT	09-324			
Civic Aerodeck (MB8)	(1.4)	4/98-2/01	TRW	12-0502			TRW	09-440			
Civic LS (EK3)	(1.5)	1/96-3/01	AK	12-0546			AT	09-324			
Civic Aerodeck (MB8)	(1.5)	4/98-2/01	TRW	12-0502			TRW	09-440			
Civic LS (EJ6)	(1.6)	1/96-3/01	AK	12-0547			AT	09-324			
Civic LS (EJ6)	(1.6)	1/96-3/01	AK	12-0546			AT	09-324			
Civic LSi (MB1)	(1.6)	2/95-12/96	TRW	12-0502			AK	12-0530			
Civic RTSi VTEC (EH1)	(1.6)	8/91-12/92	AK	12-0547			AK	09-325			
Civic RTSi VTEC (EH1) (ABS)	(1.6)	1/92-12/95	AK	12-0546			AK	12-0548			
Civic SR VTEC (EJ8)	(1.6)	1/96-3/01	AK	12-0546			AT	09-324			
Civic SRi VTEC (MB1) (ABS)	(1.6)	2/95-12/96	TRW	12-0502			AK	12-0530			
Civic VTi (3 Drs) (EK4)	(1.6)	1/96-3/01	AK	12-0546			AK	12-0548			
Civic VTi (4 Drs) (EK4)	(1.6)	1/96-3/01	AK	12-0547			AK	12-0548			
Civic Aerodeck (MC1)	(1.6)	4/98-2/01	TRW	12-0502			AK	12-0530			
Civic Aerodeck (MC2)	(1.8)	4/98-2/01	AK	12-0543			AK	12-0544			
Civic TDiC	(2.0)	01/97-10/00	TRW	12-0502			AK	12-0530			
Civic VII											
Civic Hatchback IS	(1.4)	2/01-9/05	AK	12-1077			AK	12-0750			
Civic Coupè	(1.6)	2/01-12/05	AK	12-1077			AK	12-0750			
Civic CDTi	(1.7)	1/02-9/05	AK	12-1077			AK	12-0750			
Civic 16V	(1.8)	2/01-9/05	SU	12-1059			AK	12-0750			
Civic Hatchback I Sport	(2.0)	9/01-9/05	AK	12-1077			AK	12-0750			

HONDA

Civic Hatchback Type R	(2.0)	9/01-9/05	AK	12-1077		AK	12-0750		
Civic VIII									
Civic Hybrid	(1.3)	1/06-	TRW	12-1245		TRW	12-1246		
Civic	(1.3)	1/06-	TRW	12-1245		TRW	12-1246		
Civic 16V	(1.4)	1/08-	TRW	12-1245		TRW	12-1246		
Civic 16V	(1.6)	1/08-	TRW	12-1245		TRW	12-1246		
Civic 16V	(1.8)	1/06-	TRW	12-1245		TRW	12-1246		
Civic 16V	(1.8)	1/06-	AK	12-0482		TRW	12-1246		
Civic GX	(1.8)	1/06-	SU	12-1059		AK	12-0750		
Civic 16V	(2.0)	1/06-	TRW	12-1245		TRW	12-1246		
Civic 16V	(2.0)	1/06-	AK	12-0482		TRW	12-1246		
Civic Type R	(2.0)	1/06-	TRW	12-1245		TRW	12-1246		
Civic Type R	(2.0)	1/06-	AK	12-0482		TRW	12-1246		
Civic CDTi	(2.2)	1/06-	TRW	12-1245		TRW	12-1246		
Civic CDTi	(2.2)	1/06-	AK	12-0482		TRW	12-1246		
Civic IX									
Civic VTEC (FK)	(1.4)	2/12-	AT	12-1369		AT	12-1528		
Civic DTEC (FK)	(1.6)	2/13-	AT	12-1369		AT	12-1528		
Civic Tourer DTEC (FK)	(1.6)	1/14-	AT	12-1369		AT	12-1528		
Civic VTEC (FK)	(1.8)	2/12-	AT	12-1369		AT	12-1528		
Civic Tourer VTEC (FK)	(1.8)	1/14-	AT	12-1369		AT	12-1528		
Civic DTEC (FK)	(2.2)	2/12-	AT	12-1369		AT	12-1528		
Civic CRX									
Civic CRX (EE6)	(1.4)	1/90-12/91	AK	12-0501		AK	09-325		
Civic CRX (AAF)	(1.5)	84-8/85	SU	12-0245		AK	09-325		
Civic CRX (AAF)	(1.5)	85-9/88	AK	12-0289		AK	09-325		
Civic CRX (AAS)	(1.5)	85-9/88	AK	12-0503		AK	09-325		
Civic CRX (ED9)	(1.6)	86-9/88	AK	12-0350		AK	12-0351		
Civic CRX (ED9)	(1.6)	88/2/92	AK	12-0479		AK	12-0351		
Civic CRX (ED9-EE6/8) <GB>	(1.6)	88-2/92	AK	12-0480		AK	12-0351		
Civic 16V CRX DOHC	(1.6)	86-8/87	AK	12-0503		AK	09-325		
Civic 16V CRX DOHC (ED9)	(1.6)	2/88-2/92	AK	12-0349		AK	12-0351		
Civic 16V CRX VTEC (EE8)	(1.6)	90-2/92	AK	12-0289		AK	12-0351		
Civic CRX ESi (EH6)	(1.6)	5/92-1/94	AK	12-0546		AK	12-0548		
Civic CRX Si (AAS)	(1.6)	83-9/88	AK	12-0503		AK	09-325		
Civic CRX Si (ED9)	(1.6)	83-2/92	AK	12-0479		AK	09-325		
Civic CRX VTi VTEC (EE8)	(1.6)	90-5/92	AK	12-0289		AK	12-0351		
Civic CRX VTi VTEC (EE8)	(1.6)	92-1/94	AK	12-0546		AK	12-0351		
Civic CRX (EJ1/6/8)	(1.6)	2/94-12/98	AK	12-0546		AK	09-325		
Civic CRX (EJ1/6/8)	(1.6)	2/94-12/98	AK	12-0547		AK	09-325		
Concerto									
Concerto	(1.4)	10/89-7/91	TRW	12-0484		TRW	09-440		
Concerto GL	(1.4)	10/89-7/91	AK	12-0479		AK	09-325		
Concerto	(1.5)	10/89-8/90	TRW	12-0484		AK	09-325		
Concerto Automatic	(1.5)	10/89-8/90	AK	12-0479		TRW	09-440		
Concerto	(1.5)	9/90-5/95	TRW	12-0502		AK	12-0397		
Concerto LX - Autom.	(1.6)	2/90-5/95	AK	12-0479		AK	09-325		
Concerto	(1.6)	10/89-8/90	TRW	12-0484		AK	09-325		
Concerto Automatic	(1.6)	10/89-8/90	AK	12-0479		TRW	09-440		
Concerto	(1.6)	9/90-5/95	TRW	12-0484		TRW	09-440		
Concerto	(1.6)	9/90-5/95	TRW	12-0502		AK	12-0397		
Concerto 16V	(1.6)	9/90-5/95	AK	12-0479		AK	09-325		
Concerto 16V	(1.6)	9/90-5/95	TRW	12-0484		TRW	09-440		
Concerto 16V SX	(1.6)	9/90-5/95	TRW	12-0502		AK	12-0397		
Concerto Diesel	(1.8)	8/94-10/96	TRW	12-0502		TRW	09-440		
Concerto Diesel (ABS)	(1.8)	8/94-10/96	TRW	12-0502		AK	12-0397		
CR-V I									
CR-V	(2.0)	1/99-2/02	AK	12-0543		AK	09-439		
CR-V II									
CR-V	(2.0)	7/02-9/06	AK	12-1117		AK	12-0750		
CR-V CTDi	(2.2)	2/05-9/06	AK	12-1117		AK	12-0750		
CR-V		7/02-9/06					09-689		(P)
CR-V		7/02-9/06					09-713		(P)
CR-V III									
CR-V VTEC	(2.0)	1/07-	BO	12-1352		BO	12-1353		
CR-V CTDi	(2.2)	1/07-	BO	12-1352		BO	12-1353		

HONDA

CR-V		1/07-					09-690			(P)
CRX										
CRX	(1.5)	85-87	SU	12-0290			AK	09-325		
CRX	(1.5)	88-91	AK	12-0289			AK	09-325		
CRX ESi	(1.6)	2/92-4/98	AK	12-0547			AK	09-325		
CRX VTEC	(1.6)	2/92-4/98	AK	12-0546			AK	12-0548		
CRX VTi	(1.6)	2/92-4/98	AK	12-0546			AK	12-0548		
CRX Del Sol										
CRX Del Sol ESi (EG-EH)	(1.6)	2/92-4/98	AK	12-0547			AK	12-0548		
CRX Del Sol VTi (EG-EH)	(1.6)	2/92-4/98	AK	12-0546			AK	12-0548		
CRX Del Sol	(1.6)	93-4/98	AK	12-0634			AK	12-0548		
CR-Z										
CR-Z Hybrid	(1.5)	6/10-	AK	12-1446			AK	12-0483		
FR-V										
FR-V SOHC VTEC	(1.7)	1/05-	SU	12-1059			AK	12-1374		
FR-V VTEC	(1.8)	1/05-	SU	12-1059			AK	12-1374		
FR-V DOHCi VTEC	(2.0)	1/05-	SU	12-1059			AK	12-1374		
FR-V CTDi	(2.2)	1/05-	SU	12-1059			AK	12-1374		
FR-V		1/05-						09-713		(P)
HR-V										
HR-V	(1.6)	1/99-	AK	12-1083			AK	09-618		
Insight										
Insight Vtec	(1.0)	4/00-12/06	AK	12-1041						
Integra										
Integra (3 doors) (DA4)	(1.5)	86-5/90	AK	12-0289			AK	09-326		
Integra (4 doors) (DA4)	(1.5)	86-5/90	AK	12-0503			AK	12-0351		
Integra (3 doors) (DA3)	(1.6)	86-5/90	AK	12-0349			AK	09-326		
Integra (4 doors) (DA3)	(1.6)	86-5/90	AK	12-0349			AK	12-0351		
Integra DOHC	(1.6)	6/90-10/97	AK	12-0480			AK	12-0548		
Integra DOHC	(1.6)	6/90-10/97	AK	12-0736			AK	12-0548		
Integra Type-R	(1.8)	11/97-10/01	AK	12-0543			AK	12-0544		
Integra 16v Type-R	(2.0)	11/01-	AK	12-0543			AK	12-0544		
Jazz I										
Jazz (all models)	(1.2)	1/84-9/86	AK	12-0292			SU	09-300		
Jazz II										
Jazz (all models)	(1.2)	3/02-7/08	AK	12-0547			MA	09-642		
Jazz GD	(1.4)	3/02-7/08	SU	12-1059			AK	12-0750		
Jazz III										
Jazz	(1.2)	7/08-	AK	12-1446			AK	12-0548		
Jazz Hybrid	(1.3)	4/11-	AK	12-1446			AK	12-0548		
Jazz	(1.4)	7/08-	AK	12-1446			AK	12-0548		
Legend										
Legend	(2.0)	4/87-3/91	AK	12-0371			AK	12-0372		
Legend <GB>	(2.0)	4/87-3/91	TRW	12-0393	*		TRW	12-0395	*	
Legend <GB>	(2.0)	4/87-3/91	TRW	12-0394	*		TRW	12-0395	*	
Legend	(2.5)	4/87-3/91	AK	12-0371			AK	12-0483		
Legend <GB>	(2.5)	4/87-3/91	TRW	12-0393	*		TRW	12-0395	*	
Legend <GB>	(2.5)	4/87-3/91	TRW	12-0394	*		TRW	12-0395	*	
Legend V6	(2.5)	4/87-3/91	AK	12-0371			AK	12-0483		
Legend V6 <GB>	(2.5)	4/87-3/91	TRW	12-0393	*		TRW	12-0395	*	
Legend V6 <GB>	(2.5)	4/87-3/91	TRW	12-0394	*		TRW	12-0395	*	
Legend	(2.7)	4/87-3/91	AK	12-0371			AK	12-0483		
Legend <GB>	(2.7)	4/87-3/91	TRW	12-0394	*		TRW	12-0395	*	
Legend Coupè	(2.7)	4/87-3/91	AK	12-0480			AK	12-0483		
Legend V6 Coupe'	(2.7)	4/87-3/91	AK	12-0371			AK	12-0483		
Legend V6 Coupe'	(3.2)	4/91-12/95	AK	12-0543			AK	12-0750		
Legend V6 Sedan	(3.2)	4/91-12/95	AK	12-0543			AK	12-0750		
Legend (all models)	(3.5)	1/96-12/97	AK	12-0543			AK	12-0544		
Legend (all models)	(3.5)	1/98-12/98	AK	12-0543			AK	12-0750		
Legend (all models)	(3.5)	1/99-	AK	12-1083			AK	12-0750		
Logo										
Logo	(1.3)	2/99-3/02	AK	12-0547			AK	09-580		
N 600										
N 600	(0.6)	66-74	DU	12-0013			SU	09-174		
N 600 S - Z Coupe'	(0.6)	69-74	SU	12-0170			AK	09-268		

HONDA

NSX										
NSX V6 (NA115)	(3.0)	9/90-12/96	AK	12-0543			AK	12-0545		
NSX V6 (NA126)	(3.0)	9/90-12/96	AK	12-0543			AK	12-0545		
NSX V6 VTEC (ALB)	(3.0)	1/92-12/96	AK	12-0543			AK	12-0545		
Odyssey										
Odyssey (RA1)		91-	AK	12-0543			AK	12-0544		
Odyssey		1/05-	AK	12-1258			AK	12-1259		
Passport										
Passport		94-95	SU	12-0580			SU	12-0581		
Prelude										
Prelude (ASN)	(1.6)	10/79-1/82	SU	12-0190			SU	09-300		
Prelude (ASN)	(1.6)	2/82-9/83	SU	12-0244			SU	09-327		
Prelude (ASN)	(1.6)	2/82-9/83	SU	12-0245			SU	09-327		
Prelude EX-EXR (AAB)	(1.8)	2/83-84	AK	12-0501			AK	12-0291		
Prelude EX-EXR (AAB)	(1.8)	85-9/87	AK	12-0289			AK	12-0291		
Prelude (BA4)	(2.0)	1/88-12/89	AK	12-0480			AK	12-0396		
Prelude (BA4)	(2.0)	1/90-8/91	AK	12-0621			AK	12-0396		
Prelude (BB3)	(2.0)	9/91-12/96	AK	12-0621			AK	12-0483		
Prelude (BB9)	(2.0)	1/97-10/00	AK	12-0621			AK	12-0750		
Prelude 4WS (BA4)	(2.0)	1/88-12/89	AK	12-0480			AK	12-0396		
Prelude 4WS (BA4)	(2.0)	1/90-10/00	AK	12-0621			AK	12-0396		
Prelude EX (ABA)	(2.0)	1/86-12/86	AK	12-0391			AK	12-0291		
Prelude EX (ABA)	(2.0)	1/87-12/87	AK	12-0392			AK	12-0291		
Prelude EX-EX 4WS (BA4)	(2.0)	1/88-12/88	AK	12-0479			AK	12-0291		
Prelude EX-EX 4WS (BA4)	(2.0)	1/89-9/91	AK	12-0479			AK	12-0396		
Prelude EXR (ABA)	(2.0)	1/86-12/86	AK	12-0391			AK	12-0291		
Prelude EXR (ABA)	(2.0)	1/87-12/87	AK	12-0392			AK	12-0291		
Prelude Si (BA)	(2.0i)	1/88-12/88	AK	12-0371			AK	12-0396		
Prelude Si (BA)	(2.0i)	1/88-12/88	AK	12-0480			AK	12-0396		
Prelude SRS (BB9)	(2.0)	1/97-10/00	AK	12-0621			AK	12-0750		
Prelude 4WS (BB1)	(2.2i)	1/93-12/96	AK	12-0621			AK	12-0483		
Prelude VTi-VTi 4WS (BB6/8)	(2.2i)	1/97-10/00	AK	12-0543			AK	12-0544		
Prelude (BB2/3)	(2.3i)	9/91-12/96	AK	12-0543			AK	12-0483		
Quintet										
Quintet (SU)	(1.6)	80-8/81	SU	12-0244			SU	09-300		
Quintet (SU)	(1.6)	81-2/85	SU	12-0244			SU	09-327		
Quintet (SU)	(1.6)	81-2/85	SU	12-0245			SU	09-327		
S2000										
S2000	(2.0)	3/99-	AK	12-1077			AK	12-0750		
Shuttle										
Shuttle ES-LS (RA1)	(2.2i)	2/95-12/97	AK	12-0543			AK	12-0750		
Shuttle ES-LS (RA3)	(2.3i)	1/98-10/00	AK	12-0543			AK	12-0750		
Stream										
Stream ES-LS	(1.7)	3/01-	SU	12-1059			AK	12-0750		
Stream S-SE	(1.7)	6/01-	SU	12-1059			AK	12-0750		
Stream ES	(2.0)	3/01-	SU	12-1059			AK	12-0750		
Stream S ES	(2.0)	6/01-	SU	12-1059			AK	12-0750		
Stream		3/01-						09-713		(P)
Vigor										
Vigor Inspire 20V (CC2)	(2.0i)	93-	AK	12-0543			AK	12-0544		
Vigor Inspire 20V (CC2)	(2.5i)	93-	AK	12-0543			AK	12-0544		